


Patch Upgrade Guidance for HD cameras

This patch is only suitable for HD cameras FI9821W V2, FI9818W V2, FI9831W, FI9826W, FI9821P, FI9831P, FI9826P,FI9805W, FI9804W, FI9804P, FI9805E, FI9805P, FI9805EP.


Note:

System firmware 1.4.1.10 and application firmware 2.x.1.120 **can** upgrade with this patch. If your cameras has other firmware version, please upgrade to the correct firmware version first.



Preparation before upgrading:

1. Please restart your camera before the upgrading;
2. Connect camera to router with an Ethernet cable before upgrading;
3. DO NOT upgrade firmware via wireless;
4. DO NOT upgrade firmware over internet, just finish it in LAN;
5. Keep power on during the upgrading;
6. Unplug the SD card before upgrading;
7. Logging your camera as administrator first, upgrade firmware on web page.



Step: Please log in the camera and go to Settings→System→Patch Installation to upgrade with this patch.

--- By Foscam Technical Support Team