


## Patch Upgrade Guidance for HD cameras

This patch is only suitable for HD cameras FI9821P V2,FI9831P V2,FI9826P V2,FI9821EP, FI9853EP,FI9851P,FI9803EP,FI9803P.

**Note:**


System firmware 1.5.3.13 and application firmware 2.x.2.31 **can** upgrade with this patch. If your cameras has other firmware version, please upgrade to the correct firmware version first.



**Preparation before upgrading:**

1. Please restart your camera before the upgrading;
2. Connect camera to router with an Ethernet cable before upgrading;
3. DO NOT upgrade firmware via wireless;
4. DO NOT upgrade firmware over internet, just finish it in LAN;
5. Keep power on during the upgrading;
6. Unplug the SD card before upgrading;
7. Logging your camera as administrator first, upgrade firmware on web page.

**Step: Please log in the camera and go to Settings→System→Patch Installation to upgrade with this patch.**



--- By Foscam Technical Support Team