


Patch Upgrade Guidance for HD cameras

This patch is only suitable for HD cameras C1,C1 V2,C1-Lite,C1-Lite V2,FI9800P, FI9800P V2,FI9803P V2,FI9803P V3,FI9815P, FI9815P V2, FI9816P,FI9816P V2,FI9851P V2/FI9800W/FI9800E/FI9800XE.


Note:

System firmware 1.9.3.16 and application firmware 2.x.2.47 **can** upgrade with this patch. If your cameras has other firmware version, please upgrade to the correct firmware version first.



Preparation before upgrading:

1. Please restart your camera before the upgrading;
2. Connect camera to router with an Ethernet cable before upgrading;
3. DO NOT upgrade firmware via wireless;
4. DO NOT upgrade firmware over internet, just finish it in LAN;
5. Keep power on during the upgrading;
6. Unplug the SD card before upgrading;
7. Logging your camera as administrator first, upgrade firmware on web page.



Step: Please log in the camera and go to Settings→System→Patch Installation to upgrade with this patch.

--- By Foscam Technical Support Team