


Upgrade Guidance for HD Cameras

This patch is for HD cameras: FI9903P. Please check your camera model on the sticker of the camera (different versions of one model share same firmware). Updating with the wrong firmware could severely damage and/or brick your camera. Please make sure the firmware is correct.

Note:

System firmware 1.8.1.9, application firmware 2.x.1.53 **can** upgrade to this patch.



Preparation before upgrading:


1. Please restart your camera before the upgrading;
2. Connect camera to router with an Ethernet cable before upgrading;
3. DO NOT upgrade firmware via wireless;
4. DO NOT upgrade firmware over internet, just finish it in LAN;
5. Keep power on during the upgrading;
6. Logging your camera as administrator first, upgrade firmware on web page.
7. Suggest to unplug SD card before upgrade.

Upgrade the Patch:

Step: Login your camera, go to **Settings-->System-->Patch Installation**.

Click Browse/Choose File, find the file

FOSIPC_C_patch_ver2.x.1.53_1_20180705_160021, you've extracted in your local hard driver, then click Open. Camera will upgrade after you click on "Install Patch".



Note: When “Upgrading, do not power off ... Xs” pop up, camera IP will disappear from the Equipment Search Tool. Then camera will reboot itself, DO NOT power off the camera, please wait till the camera IP reappear in the Equipment Search Tool.

End

--- By Foscam Technical Support Team